

Guarantee

Opticron Microstands are of a very high quality both in their performance and construction. We guarantee some parts in these instruments for up to 5 years under the following conditions:

- (i) In the case of defects attributable to faulty processing or materials, we will assume responsibility for the labour and material costs during the first 2 years after purchase. We reserve the right to decide whether defective parts should be repaired or replaced.
- (ii) During the next 3 years we will assume responsibility for material costs only, charging corresponding labour costs.
- (iii) We will accept no liability for damage caused by incorrect use, water penetration, or for any repairs or actions which have been carried out outside our firm.

This guarantee is in addition and does not affect your statutory rights.

opticron

Unit 21, Titan Court, Laporte Way, Luton,
Bedfordshire, LU4 8EF, UK

Phone: +44 (0)1582 726522 Fax: +44 (0)1582 723559

Email: sales@opticron.co.uk

opticron



30259 Microstand 3x LED

For use with 4x12 and 8x20

Gallery Scopes

User Guide and Guarantee

Microstand conversions increase basic monocular magnification by a factor of 3.

Instructions:

- (1) Screw the microstand into the objective lens end of the gallery scope
- (2) Attach the LED unit to the microstand
- (3) Place the microstand centrally over the object to be viewed
- (4) Rotate the focusing band on the gallery scope to bring the object into sharp focus



Specifications:

30259 3x Microstand with LED illuminator

Base area 62x55mm

Height 88mm. Weight 68g

LED (Light Emitting Diode)

Power source: CR2016 lithium batteries

Battery life: 16 hours

ø26mm x 34mm. Weight 13g

How to replace the battery:

- (1) Unscrew knob from top of unit
- (2) Remove the retaining spring clip from the LED light unit
- (3) Separate the unit into two pieces
- (4) Replace both batteries
- (5) Close the unit and retain it with the spring clip
- (6) Replace knob