

Guarantee

Please keep this Guarantee Card in a safe place

Model:.....

Purchase date:.....

Dealer:

Opticron T3 Trailfinder WP monoculars are of a very high quality both in their performance and construction. We guarantee some parts in these instruments for up to 5 years under the following conditions:

- (i) In the case of defects attributable to faulty processing or materials, we will assume responsibility for the labour and material costs during the first 2 years after purchase. We reserve the right to decide whether defective parts should be repaired or replaced.
- (ii) During the next 3 years we will assume responsibility for material costs only, charging corresponding labour costs.
- (iii) We will accept no liability for damage caused by incorrect use, water penetration - unless the unit is specified to be waterproof, or for any repairs or actions which have been carried out outside our firm.
- (iv) Parts such as carrying straps, rubber eyecups, rubberised coatings etc. are excluded from the guarantee.

This guarantee is in addition and does not affect your statutory rights.

Registration

If you would like to register your purchase with us please visit www.opticron.co.uk and complete the online Product Registration Form.

Alternatively please telephone us during normal working hours on the numbers given. We will need the product name and serial number (if applicable), purchase date and outlet, your name and postcode.

Registration is voluntary and failure to register will not diminish your rights under the guarantee.

Privacy

Opticron takes your privacy seriously and we do not share personal information with other companies.

Contact us

Address: Unit 21, Titan Court, Laporte Way, Luton, Bedfordshire, LU4 8EF, UK

Phone: +44 (0)1582 726522

Fax: +44 (0)1582 723559

Email: sales@opticron.co.uk

opticron

T3 Trailfinder WP Monocular

User Instructions and
5 Year Guarantee



Models
8x25
10x25


User Instructions

Monoculars can open up a whole range of new and exciting impressions when travelling on holiday, taken to sporting and leisure events or used as part of a hobby such as birdwatching or astronomy. To help you get the best results from your equipment please read the following instructions carefully.

Focusing. To focus at different distances simply push or pull the focusing slider back and forth until a clear and sharp image is obtained.

Integral rubber objective lens cap. Fitted to the objective barrel, this protective cap is designed to be easily removed and replaced before and after use.

Rubber eyepiece cap. Packed separately with each monocular this cap can be fitted to the eyepiece tube in the same way as the rubber objective lens cap providing protection to the eyepiece lens when the monocular is not in use.



Adjustable Strap. Packed separately with each monocular the strap is fitted by passing the thin loop through the strap lug on the body of the monocular and then passing the thick end of the strap through the small loop and pulling tight.

Rubber Eyecups are designed to position your eyes correctly to get the maximum comfortable field of view with or without glasses and are often unique to each individual monocular.

Using glasses. T3 monoculars provide the full field of view for many spectacle wearers. To maximise field of view with glasses on, turn eyecup assembly clockwise into the 'down' position - remembering to return it to the upright position if you or anybody else wants to use the instrument without glasses.

Care and cleaning. Monoculars require little maintenance but occasionally the outside surfaces of the eyepiece and objective lens will need cleaning. To avoid damaging these surfaces please read the following carefully.

- (i) Gently remove excess dirt and dust using compressed air or blower brush.
Caution: Hard and persistent rubbing of dirty surfaces can cause abrasive scratches on the surface of the glass which may distort viewing.
- (ii) Breathe on exposed glass surface and then wipe with an optical cleaning cloth in a circular motion until the surface is clean again.

Do not attempt to dismantle the instrument as this will invalidate the guarantee.

Cold weather. In cold weather the external lens surfaces may steam up when moving the instrument from cooler air outside to warmer air inside. If this occurs, leave the instrument to stand for a few minutes until any condensation evaporates.

WARNING. Never under any circumstances use this monocular to view the Sun. Doing so may cause serious damage to your eyes.

We hope you will get a great deal of pleasure from your new T3 monocular. If you have any problems or damage it in any way our Service Department is on hand to help you.